

WARNING:

Be certain all power is OFF! Wire according to local and national codes. This product should be installed by a qualified electrician.

Directions for Mounting use only.

INSTALLING ADAPTER INTO TRACK SYSTEM

- 1) Ensure, **Circuit Selector Switch** is in the 0 (off) and **Locking Arm** is in the unlocked position prior to installation, (See Figure 2.)
- 2) Insert **Adapter** into Tek Track Series, Rotate **Locking Arm** 90 ° clockwise to lock adapter into track, (As Shown in Figure 1.)




Figure 1

- 3) Move **Circuit Selector Switch** to either **Position 1** for circuit 1 or **Position 2** for circuit 2. (See figure 2.)

NOTE: Do Not pull straight down or drag in track liner as damage may occur.

REMOVING ADAPTER TRACK SYSTEM

- 1) Move **Circuit Selector Switch** to the 0 (Off) position, (As shown in figure 2.)
- 2) Rotate **Locking Arm** 90 ° counter-clockwise to unlock **Adapter** from track liner, (See figure 2.)
- 3) Pull **Adapter** out of track system in a downward arc motion to avoid damage to the track system, (As shown in figure 1.)





Figure 2

Suitable for
Tek Track Series only