


RETROFIT COMPARISON


Select existing configuration where retrofit will be used. Note: All locations on a job may require different retrofit configurations- see separate page for measurement requirements

INSTALLATION CONDITIONS AT RETROFIT LOCATION- SHOWING INSTALLATION SYSTEM


OPENING (APERTURE)
IN DRYWALL CEILING
OPEN ABOVE



OPENING (APERTURE)
VERTICAL LIP BELOW
CEILING
OPEN ABOVE



EXISTING FIXED
FRAME OR PLATE
VERTICAL LIP BELOW
CEILING
OPEN ABOVE



EXISTING
ENCLOSURE
ABOVE CEILING
WITH POWER
FEED LOCATION

