



## Gamma Cylinder Series Wall Mount Installation Instructions


WARNING: Be certain all power is OFF! Wire according to local and national codes. This product should be installed by a qualified electrician.




Remove Mounting Plate by taking out self-sealing screw.
 a. Put the screw and fixture aside for now.



- 5. Take fixture and Align Wall Arm with Mounting Plate.
  - a. "Tabs" on Mounting Plate align with "Slots" inside Wall Arm.
  - b. Engage "Tabs" first, then move inwards and downwards.



- Attach Mounting Plate to Octagonal J-box (not included) in wall, as shown above.
  a. Note the "Tabs" (left) and "Slots" (right) for step 4.
- 3. Make any necessary Power connections with fixture in accordance with Local and National Codes.
- **4.** For **Wet Location Installation**, apply <u>Silicone Sealant (not included)</u> where the Wall Arm will meet the Mounting Surface on all surfaces.



- 6. Insert Self-Sealing screw and tighten until Wall Arm is flush to wall.
- 7. For Wet Location Installation, apply <u>Silicone Sealant (not included)</u> where the Wall Arm meets the Mounting Surface on all sides.

Date: 4/5/2021 Part #: 95-1716 Rev: B Page: 1 of 1

www.speclight.com 994 Jefferson St. Fall River, MA 02721 Tel: 508-678-2303 Fax: 508-678-2260