



Disconnect power at electrical panel prior to installation and maintenance. Install in accordance with local regulations and National Electric Code by a person familiar with the construction and operation of the product and the hazards involved. Use only mating parts and accessories supplied by Spectrum Lighting.

Note: LUMINAIRE may be installed with light aimed toward floor or ceiling.

1. MOUNT CROSSBAR TO J-BOX

- Mount CROSSBAR to J-BOX using two screws with bends away from wall and 45° FLANGE parallel to floor.

2. WIRE LUMINAIRE TO PROPER SUPPLY VOLTAGE USING SUITABLE WIRE CONNECTORS (BY OTHERS).

- Connect CROSSBAR bare copper GROUND and LUMINAIRE bare copper GROUND to supply ground wire.
- Connect LUMINAIRE white neutral to supply neutral wire, LUMINAIRE black wire to hot supply wire. Place all splices in J-BOX.

FOR 0-10V DIMMING.

- Connect LUMINAIRE pink wire to control pink or grey wire.
- Connect LUMINAIRE purple wire to control purple wire.

ELV AND TRIAC DIMMING.

- Follow dimmer wiring diagram to connect LUMINAIRE white and black leads.

LUTRON DIMMING

- Follow dimmer wiring diagram to connect 2 LUMINAIRE purple wires.

Cap control wires separately if they are not being used.




Fig. 1




Fig. 2

3. ATTACH LUMINAIRE TO CROSSBAR FIG. 2

- Place wires and splices in J-BOX.
- Loosen SET SCREW.
- Install LUMINAIRE side opposite SET SCREW to one 45° CROSSBAR FLANGE.
- Move LUMINAIRE over CROSSBAR and flat against wall surface ensuring wires are not pinched and inside J-BOX.

4. TIGHTEN SET SCREW. FIG. 3.




Fig. 3