

Disconnect power at electrical panel prior to installation and maintenance. Install in accordance with local regulations and National Electric Code by a person familiar with the construction and operation of the product and the hazards involved. Use only mating parts and accessories supplied by Spectrum Lighting.

CAUTION: Do Not Mount on Wall.

INSTRUCTIONS FOR UNITS WITH DRIVER INSIDE BODY.

1. MOUNT CROSSBAR TO J-BOX

- Mount CROSSBAR to J-BOX using two screws.
Crossbar springs inside J-BOX.

2. WIRE BODY TO PROPER SUPPLY VOLTAGE USING SUITABLE WIRE CONNECTORS (BY OTHERS).

- Run BODY wires through center of CROSSBAR.
- Connect CROSSBAR BARE COPPER ground and BODY bare copper ground to supply ground wire.
- Connect BODY white neutral wire to Supply Neutral wire.
- Connect BODY black wire to hot supply wire.
- Place all splices in J-BOX.

FOR 0-10V DIMMING.

- Connect BODY pink wire to dimming system pink or grey wire.
- Connect BODY purple wire to dimming system purple wire.

ELV AND TRIAC DIMMING.

- Follow dimmer wiring diagram to connect BODY white and black leads.

Cap BODY control wires pink and purple separately if they are not being used.

4. ATTACH BODY TO CROSSBAR

- Place wires and splices in J-BOX.
- Push BODY against CROSSBAR passing BALL through center of CROSSBAR until BALL snaps over CROSSBAR SPRINGS taking care not to pinch wires. Fig. 2

TO REMOVE BODY AFTER INSTALLATION FIG. 1

- Push BODY to side while pulling away from ceiling.




Fig. 1




Fig. 2