



Disconnect power at electrical panel prior to installation and maintenance. Install in accordance with local regulations and National Electric Code by a person familiar with the construction and operation of the product and the hazards involved. Use only mating parts and accessories supplied by Spectrum Lighting.

INSTRUCTIONS FOR CONDUIT INTEGRAL DRIVER.

1. MOUNT TO J-BOX:

MOUNT BRACKET TO SURFACE MOUNTED

J-BOX. Fig. 1

- Route SUPPLY WIRES through BUSHING in center of J-BOX COVER.
- Use proper SCREWS (by others) to mount MOUNTING BRACKET to structure over J-BOX.
- Tighten SCREWS to secure MOUNTING BRACKET.

MOUNT J-BOX COVER TO UNISTRUT MOUNTED

J-BOX. Fig. 2

- Route SUPPLY WIRES through BUSHING in center of J-BOX COVER.
- Use KEY SLOTS on J-BOX COVER to mount MOUNTING BRACKET to J-BOX SCREWS (by others) when mounting to Unistrut beam.

2. INSTALL CANOPY TO BRACKET. Fig. 3

- Route SUPPLY WIRES and J-BOX COVER bare copper wire through hole in center of CANOPY.
- Place CANOPY on BRACKET and screw 4X SET SCREWS into CAPTIVE NUTS.

3. CONNECT CORD WIRES TO PROPER SUPPLY

VOLTAGE USING SUITABLE WIRE CONNECTORS (BY OTHERS). Fig. 4

- Connect J-BOX COVER bare copper wire and DRIVER ground wire to supply ground wire.
- Connect white neutral supply to white DRIVER wire.
- Connect black hot supply to black DRIVER wire.

FOR 0-10V DIMMING. CONNECT CORD WIRES TO PROPER CONTROL SYSTEM WIRES.

- Connect DRIVER pink wire with control system pink or grey wire. Connect purple DRIVER wire to purple control system wire.

ELV AND TRIAC DIMMING.

- Follow dimmer wiring diagram connect to DRIVER white and black leads.

Cap DRIVER control wires pink and purple separately if they are not being used.

Place all splices in MOUNTING BRACKET through CANOPY hole.

4. ATTACH BODY TO BRACKET FIG. 5

- Push wires and splices safely into MOUNTING BRACKET through center CANOPY hole.
- Push BODY against CANOPY passing BALL through center of MOUNTING BRACKET until BALL snaps over MOUNTING BRACKET SPRINGS taking care not to pinch wires.

TO REMOVE BODY AFTER INSTALLATION

Push BODY to side while pulling away from ceiling.




Fig. 1




Fig. 2




Fig. 3




Fig. 4




Fig. 5