



Disconnect power at electrical panel prior to installation and maintenance. Install in accordance with local regulations and National Electric Code by a person familiar with the construction and operation of the product and the hazards involved. Use only mating parts and accessories supplied by Spectrum Lighting.

INSTRUCTIONS FOR CONDUIT REMOTE DRIVER.

1. CONNECT DRIVER WIRES TO PROPER SUPPLY VOLTAGE USING SUITABLE WIRE CONNECTORS (BY OTHERS).

Fig.1

- Connect J-BOX COVER BARE COPPER WIRE and green ground DRIVER WIRE to supply ground wire.
- Connect white neutral supply to white DRIVER wire.
- Connect black hot supply to black DRIVER wire.

FOR 0-10V DIMMING. CONNECT DRIVER WIRES TO PROPER CONTROL SYSTEM WIRES.

- Connect DRIVER pink wire with control system pink or grey wire. Connect purple DRIVER wire to purple control system wire.

ELV AND TRIAC DIMMING.

- Follow dimmer wiring diagram connect to DRIVER white and black leads.
- Cap DRIVER control wires pink and purple separately if they are not being used.

LUTRON DRIVER CONTROL WIRES (2) PURPLE

- Connect (1) DRIVER purple wire to (1) control system purple wire.
- Connect other DRIVER purple wire to other control system purple wire.
- Place all splices in J-BOX.

2. MOUNT TO J-BOX:

MOUNT BRACKET TO SURFACE MOUNTED

J-BOX. Fig.2

- Use proper SCREWS (by others) to mount MOUNTING BRACKET to structure over J-BOX.
- Tighten SCREWS to secure MOUNTING BRACKET.



MOUNT J-BOX COVER TO UNISTRUT MOUNTED

J-BOX. Fig.1

- Use KEY SLOTS on J-BOX COVER to mount MOUNTING BRACKET to J-BOX SCREWS (by others) when mounting to Unistrut beam.
- Tighten SCREWS to secure MOUNTING BRACKET.

3. INSTALL CANOPY TO BRACKET. Fig.3

- Route blue and red SUPPLY WIRES through hole in center of CANOPY.
- Place CANOPY on BRACKET and screw 4X SET SCREWS into CAPTIVE NUTS.



4. **CONNECT FIXTURE WIRES TO DRIVER LED WIRES.**

Fig.4

- Connect LED (-) from DRIVER to LED (-) blue FIXTURE wire.
- Connect LED (+) from DRIVER to LED (+) red FIXTURE wire.

5. **ATTACH BODY TO BRACKET FIG. 5**

- Push wires and splices safely into MOUNTING BRACKET through center CANOPY hole.
- Push BODY against CANOPY passing BALL through center of MOUNTING BRACKET until BALL snaps over MOUNTING BRACKET SPRINGS taking care not to pinch wires.

TO REMOVE BODY AFTER INSTALLATION

Push BODY to side while pulling away from ceiling.




Fig.4




Fig.5